

Name

BUFFER	Mode :	<input type="text" value="Double"/>		<input type="text" value="Double"/>	
	Distance - Ft.	<input type="text" value="44.0"/>	<input type="text" value="44.0"/>	<input type="text" value="30.0"/>	<input type="text" value="12.0"/>
OIL	Mode :	<input type="text" value="Double"/>		<input type="text" value="Double"/>	
	Distances - Ft.	<input type="text" value="15.0"/>	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>
	left outside :	<input type="text" value="18.0"/>	<input type="text" value="18.0"/>	<input type="text" value="18.0"/>	<input type="text" value="10.0"/>
	left track :	<input type="text" value="30.0"/>	<input type="text" value="30.0"/>	<input type="text" value="30.0"/>	<input type="text" value="12.0"/>
	left inside :	<input type="text" value="30.0"/>	<input type="text" value="30.0"/>	<input type="text" value="30.0"/>	<input type="text" value="12.0"/>
	right inside :	<input type="text" value="18.0"/>	<input type="text" value="18.0"/>	<input type="text" value="18.0"/>	<input type="text" value="10.0"/>
	right track :	<input type="text" value="15.0"/>	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>
right outside :	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	<input type="text" value="100"/>	
Transfer Rate %					

Short Run Mode	<input type="text" value="Off"/>
Turn-around Distance	<input type="text" value="0.0"/> Ft.

Stripping Mode	<input type="text" value="Full"/>
Start	<input type="text" value="0.0"/> Ft.
Cleaner Pad Distance	<input type="text" value="61.5"/> Ft.
Vacuum	<input type="text" value="On Start"/>

Cleaner Flow	
In oil	<input type="text" value="90"/> %
Back lane	<input type="text" value="20"/> %

SPEED SETTINGS:	Pass 1	Forward	Reverse	Pass 2	Forward	Reverse
	Travel	High	High	High	High	High
	Condition	High	High	Medium	Medium	Medium
Strip	Medium					

RECOMMENDED STARTING PATTERN ONLY. The viscosity of the oil used, ambient temperature, and lane surface will affect final result. Verify pattern using a Computer Lane Monitor and perform and verify volume using Oil Fill Bottle #SA1227.

WICKS:
 Center tanks, black felt wicks #A0998J
 Track tanks, blue foam #294115487
 Outside tanks, red foam #294115485

For assistance please call 1-866-460-7263 ext. 6220

Graph layers :	
<input checked="" type="checkbox"/>	Oil Pass 1 Forward
<input checked="" type="checkbox"/>	Oil Pass 1 Reverse
<input checked="" type="checkbox"/>	Oil Pass 2 Forward
<input checked="" type="checkbox"/>	Oil Pass 2 Reverse
<input type="checkbox"/>	Stripping

